

# Kiddy Cots Link Playpen Assembly Instructions

## Step 1 - ADDING LINK CONNECTORS TO TIMBER PANELS


- slide link connector male part (A) onto end of timber panel
- insert and tighten screw in to predrilled hole



- slide link connector female part (B) onto opposite end of timber panel
- insert and tighten screw in to predrilled hole



- repeat on other ends of timber panel
- you should now have 4 link connectors on each timber panel
- see illustration as to how each panel should look when all link connectors are in the correct position




- repeat these steps until ALL panels have link connectors

**IMPORTANT:** All male and female connectors must be the same on every panel. Every panel must look the same.

## Step 2 - CONNECTING TIMBER PANELS TOGETHER

- connect panels together by lining up both top and bottom male and female parts with the desired angle



- press down firmly to connect
- repeat with all panels choosing the desired angle for each piece

### Step 3 - DISASSEMBLY

- place downward pressure on left panel with your left hand
- pull up on adjoining right panel with your right hand, this releases the connection between the male and female connectors

## **WARNING**

- To prevent serious injury or death, securely install enclosure and use according to manufacturer's instructions.
- Never use with a child able to climb over or dislodge the gate or enclosure.
- Never leave child unattended.
- Use only with the locking/latching mechanism securely engaged.
- Suitable for children from 6 months to 24 months
- This product is not to be used with a child able to climb over or dislodge/open the playpen.

### **IMPORTANT!**

- PLEASE KEEP FOR FUTURE REFERENCE.
- CLEAN PRODUCT WITH WARM WATER.
- IF ASSEMBLED ACCORDING TO INSTRUCTIONS, PLAYPEN CONFORMS TO ATSM F1004-13 STANDARD