


HiLo Highchair



Designed and manufactured to EN 14988 +A1:2012.

IMPORTANT: Thank you for choosing our product. Please read and understand these instructions before using this highchair. If in doubt, please seek help from our Customer Service Team.

Please retain these instructions for future reference.

Images in this manual are representative only. Actual product may vary. The manufacturer reserves the right to change specifications without prior notice.

SAFETY

THANK YOU FOR CHOOSING OUR PRODUCT. PLEASE TAKE A LITTLE TIME TO READ THE IMPORTANT SAFETY NOTES BELOW. THIS WILL ENSURE MANY YEARS OF HAPPY AND SAFE USE.



WARNING

WARNING! Do not use the highchair until your child can sit up unaided (6-36 months).

WARNING! Do not leave the child unattended.

WARNING! Ensure your child wears a correctly fitted and adjusted harness at all times.

WARNING! Do not use the highchair unless all components are correctly fitted and adjusted.

WARNING! Be aware of the risk of open fire and other sources of strong heat, such as electric bar fires, gas fires etc. or where a child could gain access to any other kind of hazard, in the vicinity of the highchair.

WARNING! Do not use if any part is broken, torn or missing.

WARNING! Do not move or carry the highchair with your child inside.

- Use only on a level and stable surface.
- Never move or carry the highchair whilst the baby is in it.
- Ensure children are clear of all moving parts before making any adjustments.
- Do not use near stairs or steps.
- When not in use, store away from children.
- Use the highchair on a flat, even and horizontal floor and do not elevate the highchair on any structure or table.
- To reduce the risk of injury, position the highchair away from furniture, walls, hot surfaces and liquids, window covering cords, electrical cords. Position the highchair away from furniture, unless the chair is being used at a table with the tray removed.
- The highchair should only be used in an upright position once the child is capable of reliably and consistently sitting upright.
- Do not use the highchair if it is not working correctly, the owner should seek repairs.

WARNING! Follow the manufacturer's instructions.

WARNING! Do not leave the child unattended.

WARNING! The harness must always be used and correctly fitted. Most injuries from highchairs are caused by falls.

WARNING! Position the highchair away from solid structures and benches to avoid injuries caused by falls and by access to dangerous items.

WARNING! Not to be used by children over 15kg due to its construction, strength and design.

- Ensure all users are familiar with the product's operation.
- Ensure your highchair is fully erected before placing your child inside.
- Do not allow your child to climb unassisted into, play with or hang onto the highchair. This is not a toy.
- All additional hazards such as electrical flex should be kept out of the reach of children in the highchair.

SAFETY

- Adult assembly is required.
- When using the highchair at a table, ensure your child cannot push against the table or another surface as this could result in the chair tipping.
- Ensure the wheel locks/ brakes are engaged when not moving the highchair.




MAINTENANCE

- Ensure all locking devices work correctly and regularly check the locks and fittings for security.
- Regularly check all parts for wear and tear.
- Do not use spray lubricants, simply wipe clean after use.

CARE




- The highchair can be cleaned by sponging with warm soapy water and a mild detergent. A mild disinfectant may be used if desired.
- Stubborn marks may be removed with a non-abrasive cleaner. Never clean with abrasive, ammonia based, bleach based or spirit type cleaners.

PARTS





ASSEMBLY

1



ASSEMBLY

2




H

G



x2

ASSEMBLY

3




WARNING!
Insert the stoppers in the front position.
DO NOT put the wheels in front position.




ASSEMBLY

4




WARNING!
Insert the wheels with brake bar
in the back position.
DO NOT put the wheels in front
position.





ASSEMBLY

5



ASSEMBLY



6



x2


ASSEMBLY

7






ASSEMBLY

8





E




USING THE HIGHCHAIR

9




USING THE HIGHCHAIR

10






USING THE HIGHCHAIR

11




USING THE HIGHCHAIR

12




USING THE HIGHCHAIR

13





USING THE HIGHCHAIR

14



FOLDING

15



Made in China

Manufactured for:
The Warehouse Ltd,
26 The Warehouse Way,
Northcote, Auckland.
0800 422 274