

# LIVING & CO<sup>®</sup>

## BUTTERFLY GAZEBO



Dimensions: 4 meters (W) x 4 meters (D) x 3m (H)

## INSTRUCTION MANUAL



AFTER SALES SUPPORT

 NZ 0800 422 274

# Important Safety Instructions

- Do not use Gazebo in windy or rainy conditions
- This product is not designed as a permanent structure.
- To prolong the life of your gazebo, Store inside when not in use.

## Assembly Details

 <p>20 minutes</p> <p><i>Approximate Assembly Time</i></p>	 <p>4 Person of Assembly</p>	 <p>4X 4 meters</p> <p><i>Required Assembly Space</i></p>
 <p>Hammer</p> <p><i>Required Assembly Tools</i></p>	 <p>Measuring tape</p>	




## Tips before you start

1. Please check that all parts are present before you start the assembly of your product.
2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
3. For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble your product safely.
4. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
5. For the protection of your product, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
6. During assembly please take care not to over-tighten any fittings, as this may damage the product. Do not use power tools.
7. Always place the product on a flat, steady and stable surface.
8. This product is intended household use only as it is a non-industrial product.
9. Please use caution and care when lifting the product to avoid personal injury and/or product damage.


## Care and maintenance

- When left exposed to the elements for a period of time, steel may rust and fabric may fade.
- To prolong the life of your furniture, clean and dry frame regularly.
- Use car polish or similar product for extra protection of metal components. Use spray lubricant or similar on nuts and bolts
- Clean fabric with a damp rag. Do not bleach.



## Part Name

 1# 4 PCS	 2# 2 PCS	 3# 2 PCS	
		 4# 4 PCS	
		 5# 4 PCS	
 6# 4 PCS		 7# 4 PCS	 8# 2 PCS
 9# 32PCS	M6*60mm  10# 8PCS	M6*45mm  11# 12PCS	 12# 8 PCS
 13# 20PCS	 14# 20PCS	 15# 20PCS	 16# 1 PC


# Assembly



# Assembly



# Assembly





# LIVING & CO<sup>®</sup>

## Warranty

We pride ourselves on producing a range of quality home appliances that are both packed with features and completely reliable. We are so confident in our products, we back them up with a ONE -year warranty. Now you too can relax knowing that you are covered.

Customer Helpline NZ: 0800 422 274  
This Product is covered by ONE -year warranty when accompanied by proof of purchase.