

Living & Co

MOOD DRUM SHADE DIY 40CM

Instructions

Please read these instructions and warnings carefully before operating to ensure safe and satisfactory operation of this product.

Please also retain these instructions for future use.

Warnings:

- When fitting a lamp shade or changing a bulb, always switch off the light at the wall socket / wall switch and allow the bulb to cool down before handling.
- Do not cover the lamp shade or bulb during use as this could be a potential safety hazard
- Always use the correct type and wattage of bulb as marked on the lamp fitting.
- Do not switch on the light until the assembly is complete.
- The shade is intended for indoor use only.
- Dispose of old bulbs carefully.

Assembly:

1. Remove protective plastic overwrap / packaging from the lamp shade.
2. Lay the lampshade material out flat on a stable / dry and level support surface.
3. Place the two circular supports perpendicular to the shade cover material and parallel to each other on the outer edges of the shade (as shown in the diagram over page).
4. Using the fastenings attached to the shade cover material, carefully clip to the circular support rails by attaching one and then rotating the support to the proceed to the next.
5. Once all clips have been attached to the circular supports, finish by folding the two ends of shade material together where they meet each other using the Velcro strip.
6. Assembly is now complete. Attach to the lampholder / lamp fitting taking care to ensure any attachment or use restrictions given by the lamp supplier.

Assembly of shade material to support frame:

