

Living & Co

WOOLA KIT ZEBRA E27 60W

Instructions

Please read these instructions and warnings carefully before operating to ensure safe and satisfactory operation of this product.

Please also retain these instructions for future use.

Warnings:

- This is a Class II product and does not require an earth connection.
- Always use the correct type and wattage of bulb.
- When changing a bulb, always switch off the light at the wall socket and allow the bulb to cool down before handling.
- Dispose of old bulbs carefully.
- Do not switch on the light until the installation is complete.
- Do not cover the lamp or bulb during use as this could be a potential safety hazard.
- Turn off the appliance when not in use.
- The luminaire is not intended for use by children unless suitable adult supervision is provided.
- Children should be supervised to ensure they do not play with the luminaire.
- The fitting is intended for indoor use only.
- If the flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the a suitably qualified person in order to avoid a hazard.
- When suspending the lamp holder by the supply cord (pendant application), ensure any fixings / hooks used are smooth and well-rounded. Do not exert force or pressure onto the supply cord sheath so as to avoid damaging the insulation.
- If attaching a lamp shade to the lamp holder, ensure its weight does not exceed 1kg.

CAUTION: Ensure that the light bulb is not within the recommended 0.5m of any surface when operating as this could be a potential safety hazard.

CAUTION: Never exceed the bulb wattage stated.

Assembly:

1. If fitting a lamp shade, ensure any protective plastic overwrap is removed.
2. Remove the threaded plastic shade ring (retaining nut) from the lamp holder.
3. Install the lamp shade onto the lamp holder body.
4. Replace the threaded plastic shade ring (retaining nut) onto the lamp holder body
5. Install the recommended bulb.
6. Position the lamp fitting as required.
7. Insert the supply cord plug into a suitable mains outlet and use the in-line cord switch to operate.

Lampshade fitment:

