

Description

Name	DK-HL860
Battery	12V7AH
Motor	12V12000 RPM for driving motor 12V4800 RPM for steering motor
Dimensions	1330*850*690mm
Speed	3-8km/h
Charging time	8-12 hours
Remote control battery	AAA battery 1.5V*2 (not included)
Applicable age	37-95 months
Charger specification	Input: 100-240V AC Output: DC15V1000mA

Assembly and Operation manual

TOYOTA


OFFICIAL
LICENSED
PRODUCT

Child's Ride-on Car

Model: DK-HL860

Age of use: 37-95 months

Maximum capacity: 35 kg



The product must be assembled by adults only,
picture is for reference only

Charging the Drive Battery:



IMPORTANT! Before using the unit for the first time the battery needs to be charged for at least **8** to **12** hours - no more than **20** hours. Once battery is depleted, recharge for **8** to **12** hours - no more than **20** hours.

IMPORTANT!

Check the drive battery and charger (supply cord, connector) for wear and damage before charging. Do not charge the battery if damage has occurred. Only replace with the same type and voltage rechargeable battery and charger supplied by the manufacturer.

- Only use the rechargeable battery (or equivalent replacement) and charger supplied with your vehicle.
- Always turn power off and charge battery after riding.
- The drive battery should be charged when depleted, or if not used regularly, once a month. Failure to charge the battery as directed will cause permanent damage to the battery and will void the warranty.

STEPS:

1. Locate Charging Port. (Page 4)
2. Plug Charger plug into unit Charging Port.
3. Plug Charger into Wall outlet.
4. When battery is fully charged, unplug charger from the wall outlet and disconnect from charger port.


NOTE: The charger may feel warm during the charging. If excessively hot, unplug and replace.

NOTE: This product has charging protection: When charging, all functions are turned OFF.



Installation steps

1. Part name



2. Parts list:

Car body 1 PC	Hood 1 PC	Rearview mirror 1 pair
Windshield 1 PC	Steering wheel 1PC	Seat 1 PC
Roll bar 1 PC	Tailgate 1 PC	Rear driving motors 1 pair
Rear wheels 2 PCS	Front wheels 2 PCS	Wheel covers 4 PCS
Remote control 1 PC	Charge 1 PC	Manual 1 PC
Socket wrenches 2 PCS	Plastic part for dashboard 1 PC	MP3 line 1 PC
2 motors version: M12 Gaskets 7 PCS; M12 Wheel bushings 7 PCS; M10 Nut 1 PC; M4*12mm Screws 16 PCS;		

Instructions

- While driving, adult supervision is required all the time
- Always wear a helmet when driving
- Please don't drive near road or on the footpath.
- It is not recommended to drive the vehicle on wet surface or on slope greater than 15-degree.
- It is recommended to drive this vehicle on smooth surface only.
- Please don't drive this vehicle outdoors when it is raining.
- Make sure that the vehicle stop completely before changing direction from forward to reverse
- Please don't allow children to operate the charger or play with the battery
- Clean the vehicle with a dry cloth only.
- Please follow the correct weight and age limits allowed to drive this vehicle.
- It is prohibited to change the circuit or add other electric parts.
- Adults must teach their children about safe driving procedures.
- Please turn the power off when not in use.
- Check the seat to ensure it has been fitted and secured with a bolt before driving.
- Inspect all wires and connection of the vehicle periodically.
- Charging the battery should only be done by adults.
- Charging plug is located underneath the seat.
- In order to avoid accidents, please ensure the vehicle is safe before driving.
- Please don't let children touch the wheels or be near them when the car is moving.
- Please mind fingers when opening and closing doors.

WARNING: To reduce the risk of injury, adult supervision is required. Never use in roadways, near motor vehicles, on or near steep inclines or steps, swimming pools or other bodies of water; always wear shoes, and never allow more than 1 rider.

Warning: This toy has no brake.

WARNING!

For safety reasons,

- *do not use this product on main roads, slopes, highways or other dangerous places.
- *children must wear shoes and protective gears when operating the vehicle.
- *children should be seated with the seat belt fasten when driving.
- *only load a maximum of 35Kg on the vehicle.
- *only children aged 37 - 95 months should be allowed on this vehicle.
- *use this toy strictly according to safety manual.
- *please check the tires, steering wheels, seats and seat belts before operating vehicle.
- *this toy vehicle should be used with caution and requires skill to avoid fall or collision with third parties.

*The supply terminals are not to be short-circuited.

*The toy should be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage, they must not be used until the damage has been repaired.

-Only use the battery specified by the manufacturer

-Only use the charger specified by the manufacturer.

Pictures are for reference only, please adhere to the original Products as standard

The product must be assembled by Adults.

Warning! Not suitable for children under 36 months.

Long cord. Strangulation hazard.

WARNING:

The car contains battery that are non-replaceable.

WARNING:

For the purposes of recharging the battery, only use only use DC adaptor. provided with this toy.

WARNING:

The remote control is not a toy. It is for adult use only, and should not be used by a child. A close adult supervision is always required. Reception range may change significantly with weather, battery, and other environmental conditions.

WARNING:


RISK OF FIRE, DO NOT BYPASS.

Fault finding

Problem: The vehicle does not drive.

Cause of the problem: the battery is flat.

Please charge after each use, and charge at least once a month. It is recommended to charge for 8-12 hours, not more than 20 hours.



To avoid short fuse or power cut off:

1. Do not overload the product. Max load is 35 Kg.
2. Do not drag any item behind this product.
3. Do not allow water or any liquid into electric parts.
4. Do not change wire system without a professional.

Problem: The car only runs for a short time.

Answer 1: The battery is low, please charge for 8-12 hours but not exceeding 20 hours.

Charge at least once a month to keep the battery cells active.

Answer 2: The battery may need to be replaced depending on its charging history and age.

Problem: The sound does not work.

Please ensure the volume is turned up and the MP3 line is not connected. Sounds from steering wheel will not work when MP3 is plugged in.


Problem: Charger overheating.

It is normal for battery and charger to be slightly warm during charging. If the charger feel excessively hot, please check for a current overload or battery short circuit.

Step 1- Install front wheels

Sequence of installing parts:


M12 gasket - M12 Wheel bushing - Front wheel(without connector) - M12 Wheel bushing - M12 gasket - M10 Nut - Wheel cover - M4*12mm Screws 3 PCS



Step 2- Install rear wheels

Sequence of installing parts:

Rear driving motor (To distinguish between "L" and "R", also need to connect the motor to the cable) - Rear Wheel - M12 Wheel bushing - M12 gasket - M10 Nut - Wheel cover - M4*12mm Screws 3 PCS




Installation steps

Step 3- Install steering wheel and Console for dashboard


Steering wheel: connect the it to the cable from dashboard (if the cable is too long, please put the cable into steering wheel), then just put it into the dashboard;

Plastic part for dashboard: just put it into the dashboard




Step 4- Connect the power cable

Connect the power cable with the battery, attach the two connectors firmly together.



Instructions

6. Remote control frequency matching




2.4G remote control manual

The first use requires code matching. This product has built-in memory, and it is unnecessary to code after replacing the battery.

1. Turn off the power of the car, press and hold the "m" key of the remote control, the first indicator light starts to flash after 3 seconds, and then release the key
2. At this time, turn on the power switch of the car, the first indicator light of the remote control will become normally on, and the code matching is successful
3. When the remote control is not in use, it will enter the sleep state after 10 seconds. Press any key to wake up.
4. Key function description: "forward", "backward", "left", "right", "s" speed regulation, "P" brake.

Press the "s" key to set the speed, one light is low speed, two lights are medium speed, three lights are high speed, only medium speed when reversing

Press the "P" key to enter the braking state, the indicator lights all flash, and press the "P" key again to exit the braking state



7. Remote control instructions

Warning! It is not suitable for children under 3 years old. There are small parts inside and there is a risk of suffocation / choking

- Install two AAA dry batteries as shown in the figure
- Use a non rechargeable battery, do not charge the battery
- Different types of batteries or old and new batteries cannot be mixed
- Take out the battery from the product in time when the battery runs out
- The positive and negative terminals of the power supply shall not be short circuited

-The package of this product contains important information, please keep it


Warning! The remote control should be used by a caregiver.

There are small parts inside and there is a risk of suffocation.


Please keep away from children.

Directions for use

4. Dashboard overview



5. MP3 music board overview




- 1.USB socket
- 2.TF socket
- 3.MP3 socket
- 4.Display
- 5.MODE choose(Radio/TF card/USB connector)
- 6.Education(Pressing for a longer time and it will lower the volume)
- 7.Story(Play/ Pause under the TF/USB functions)
- 8.Music(Pressing for a longer time and it will higher the volume)

Installation steps


Step 5-Install the seat

- A. Place the seat in the car body slot as shown in the figure.
- B. Lock the seat latch as shown in the figure.



Step 6-Install the tailgate.


- Place the tailgate in the car body slot as shown in the figure.



Installation steps


Step 7-Install the roll bar.

Place the roll bar in the car body slot as shown in the figure.



Step 8- Install windshield and rearview mirror


- Place the windshield in the car body slot as shown in the figure, then lock it by 2 PCS of M4*12 screws;
- Insert the rearview mirror into the dashboard slot as shown in the figure;



Installation steps

Step 9-Install the hood

Place the hood in the car body slot as shown in the figure.



Carry Handle

The carry handle is at the rear floor of the car. Pull it out and, you can easily pull and push the car.

