

145.00 mm

# LIVING&CO

## Warranty

We pride ourselves on producing a range of quality home appliances that are both packed with features and completely reliable. We are so confident in our products, we back them up with a 1 year warranty. Now you too can relax knowing that you are covered.

Customer Helpline NZ: 0800 422 274

This Product is covered by 1 year warranty when accompanied by proof of purchase.

LIVING&CO

AFTER SALES SUPPORT



# LIVING&CO

## COMPACT GRILL 2000W



## INSTRUCTION MANUAL

### LHG2000W

**Important: Read all instructions carefully before using this appliance. Retain those instructions for further reference.**

AFTER SALES SUPPORT



210.00 mm

## Contents

- 03 IMPORTANT SAFEGUARDS
- 05 IMPORTANT SAFEGUARDS(CONT.)
- 06 PARTS IDENTIFICATION
- 07 BEFORE FIRST USE
- 08 HOW TO USE
- 10 CLEANING AND CARE
- 11 STORGE

## CLEANING AND CARE(CONT.)

- Do not use metal utensils to remove your foods, they can damage the non-stick surface.
- Wipe the outside of the Health Grill with a damp cloth only. Do not clean the outside with any abrasive scouring pad or steel wool, as this will damage the finish. Do not immerse in water or any other liquid.
- Do not place in the dishwasher.
- Remove and empty the drip tray after each use and wash the tray in warm, soapy water. Avoid the use of scouring pads or harsh detergents as they may damage the surface. Rinse and dry thoroughly with a clean, soft cloth and replace.

## STORAGE

- Always unplug the Health Grill before storage.
- Always make sure the Health Grill is cool and dry before storing.
- The power cord can be wrapped around the bottom of base for storing.

## CLEANING AND CARE

- Always unplug the Health Grill and allow it to cool before cleaning. The unit is easier to clean when slightly warm. There is no need to disassemble Health Grill for cleaning. Never immerse the Health Grill in water or place in dishwasher.
- Wipe cooking plates with a soft to remove food residue. For baked on food residue squeeze some warm water mixed with detergent over the food residue then clean with a non-abrasive plastic scouring pad or place wet kitchen paper over the grill to moisten the food residue.
- Do not use anything abrasive that can scratch or damage the non-stick coating.

## IMPORTANT SAFEGUARDS

When using an electrical appliance, basic precautions should always be observed to reduce risk of electric shock, fire, and injury to persons or property, including the following.

1. Read all instructions.
2. Make sure that your outlet voltage corresponds to the voltage stated on the rating label.
3. Do not let cord hang over edge of table or counter, or touch hot surface.
4. Do not operate the appliance with a damaged cord or plug, or after the appliance malfunction, or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or adjustment.
5. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
6. Children should be supervised to ensure that they do not play with the appliance.
7. The use of accessory not recommended by the appliance manufacturer may result in fire, electric shock or injury to persons.
8. Unplug from outlet when not in use and before cleaning. Always allow to cool before putting on or taking off parts, and before cleaning the appliance.

## IMPORTANT SAFEGUARDS

9. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

10. Children should be supervised to ensure that they do not play with the appliance.

11. To protect against fire, electric shock and injury to persons, do not immerse the appliance, cord or plug in water or other liquid. If this has happened, do not use this appliance any more, dispose of the appliance.

12. This appliance has been incorporated with a grounded plug. Please ensure the wall outlet in your house is well earthed.

13. Do not leave the appliance unattended when it is plugged. Unplug the appliance immediately after use.

14. Always use the appliance on a secure, dry level surface.


15. Do not place on or near a hot gas or electric burner, or in a heated oven.

## USE AS OPEN GRILL (CONT.)

- With your left hand on the handle, use your right hand to slide the lever toward you. Push the handle back until the cover rests flat on the counter. The unit will stay in this position until you lift the handle and cover to return it to the closed position.

- Use the Health Grill as an open grill to cook burgers, steak, poultry (we do not recommend cooking bone-in chicken, since it does not cook evenly on an open grill), fish and vegetables.

- Cooking on the open grill is the most versatile method of using the Health Grill. In the open position, you have double the surface area for grill.




- You have the option of cooking different types of foods on separate surfaces without combining their flavors, or cooking large amounts of the same type of food. The open position also accommodates different cuts of meat with varying thicknesses, allowing you to cook each piece to your liking.

## HOW TO USE(CONT.)

- When the ready-to-cook light (Green) is illuminated, the grill reaches the preset temperature and is ready for cook. It will take approximately 5 minutes.
- Open the Health Grill, put the sandwich, meat or other foods on the bottom cooking plate and close the grill.
- Cook for about 3 to 8 minutes, during this time, the ready-to-cook light may go on and off several times.
- When the food is cooked, use the handle to open the lid. Remove the foods with the help of a plastic/wood spatula. Never use metal tongs or a knife as these can cause damage to the non-stick coating of the cook plates.
- Once you finish cooking, turn the temperature control to off position, disconnect the plug from the wall outlet and leave unit open to cool.

## USE AS OPEN GRILL


- Place Health Grill on a clean flat surface where you intend to cook. The Health Grill can be positioned in flat position.
- Upper plate/cover is level with lower plate/base. The upper and lower plates line up to create one large cooking surface. The Health Grill to this position, locate the hinge release lever on the right arm.



## IMPORTANT SAFEGUARDS(CONT.)

16. Do not clean container with cleansers, steel wool pads, or other abrasive material.
17. Never insert oversized food or metal foil or other utensils into the appliance.
18. The outer surface will get hot when the appliance is operating. Do not touch hot surface. Use handle or knobs only.
19. Do not use outdoors or for commercial purpose. Do not use appliance for other than its intended use
20. This appliance is intended to be used in household and similar applications such as:
  - Staff kitchen areas in shops, offices and other working environments;
  - Farm houses;
  - By clients in hotels, motels and other residential type environments;
  - Bed and breakfast type environments.
21. The appliance is not intended to be operated by means of an external timer or separate remote-control system.
22. Never operate the appliance with wet hands.
23. It is recommended to have a residual current device (safety switch) installed by qualified electrician to provide additional safety protection when using all electrical appliances.

## PARTS IDENTIFICATION



1. Upper Housing
2. Handle
3. Upper Plate
4. Hinge Release Lever
5. Bottom Housing
6. Ready-to-Cook Light (Green)
7. Power Light (Red)
8. Thermostat Knob
9. Oil Tray
10. Bottom Plate

## BEFORE FIRST USE

- Read all instructions carefully and keep them for future reference.
- Remove all packaging
- Clean the Cooking Plates by wiping a sponge or cloth dampened in warm water.

**DO NOT IMMERSE THE UNIT AND DO NOT RUN WATER DIRECTLY ONT THE COOKING SURFACES.**

- Dry with a cloth or paper towel.
- For best results, lightly coat the cooking plates with a little cooking oil or cooking spray.

**Notice: When your Health Grill is heated for the first time, it may emit slight smoke or odor. This is normal with many heating appliances. This does not affect the safety of your appliance.**

## HOW TO USE

- Before use, check that the temperature control is at 'OFF' position. Close the grill and plug it to a 230V~ power mains, you will notice that the power light and ready-to-cook light will be illuminated.
- Set the Grill Temperature to your desired setting. At first, try a setting at the maximum. You may later adjust it per your preference. when you see the ready-to-cook light (Green) comes off, the Health Grill has begun preheating.