


# GARDEN SHED ASSEMBLY INSTRUCTION



**Model number: 150819-Z**  
**Size: 152x78X195cm**

**PLEASE READ THE ASSEMBLY INSTRUCTION CAREFULLY  
BEFORE USE.**

## **GENERAL SAFETY WARNINGS AND INSTALLATION ADVICE**

### **KEEP WORK AREA CLEAN AND DRY.**

Cluttered, damp, or wet work areas may cause injuries.

### **STAY ALERT.**

Do not use this product when you are tired or distracted from the job at hand. We recommend that you use gloves during assembly to avoid possible cut injuries.

### **MAINTAIN A SAFE WORKING ENVIRONMENT.**

Keep the work area well. Make sure there is adequate surrounding workspace. Avoid high traffic areas. Always keep the work area free of obstructions, grease, oil, trash, and other debris.

### **PROPER LOCATION.**

Make sure the Garden shed is located on a flat level surface.

### **DO NOT INSTALL THE GARDEN SHED IN AREAS SUBJECT TO HIGH WINDS OR ASSEMBLE ON A WINDY DAY.**

Although this shed is designed to withstand greater wind loads than other conventional sheds, do not install it in areas subject to high winds or erect on a windy day. Any building left partially constructed may be seriously damaged if left in that state. It is your responsibility to safely and securely anchor the shed, having regard to the windiest conditions in the area.

## **CHECK PARTS BEFORE ASSEMBLY.**

All parts have been well labeled. Please sort, separate and identify all parts and hardware before construction, and check against the Parts List in this manual.

## **FULLY ASSEMBLE THE PRODUCT IN ONE SESSION**

Please assemble the product in one session. Assembly interruptions may cause the unexpected damage to the shed

## **REQUIRED TOOLS**

The following tools are required for the erection of the garden shed. These tools should be at hand before starting work:

1. Step ladder

2. Spanner

3. Measuring tape

4. Cordless power screw driver









5. Power drill






## **NOTE:**





Due to uneven ground and different self-assembly techniques, you may need re-drill some screw holes when assembly.





The warnings, precautions, and instructions discussed in this manual cannot cover all possible conditions and situations that may occur.





# PARTS LIST







FRONT FRAME PARTS LIST		
SKETCH	PART NO.	QTY
	F1	1
	F2	1
	F3	1
	F4	1
	F5	1
	F6	1
	F7	1
	F10	1










ROOF PARTS LIST		
SKETCH	PART NO.	QTY
	T1	1
	T2	1
	T3	1
	T4	2
	T5	1

LEFT FRAME PARTS LIST		
SKETCH	PART NO.	QTY
	L1	1
	L2	1
	L3	1
	L4	1


RIGHT FRAME PARTS LIST		
SKETCH	PART NO.	QTY
	R1	1
	R2	1
	R3	1
	R4	1

BACK FRAME PARTS LIST		
SKETCH	PART NO.	QTY
	B1	1
	B2	1
	B3	1
	B4	1

DOOR PARTS LIST		
SKETCH	PART NO.	QTY
	DL1	1
	DL2	1
	DL3	1
	DL4	1
	DL5	1
	DL6	1


ACCESSORIES LIST		
SKETCH	PART NO.	QTY
	W1	2
	W2-1	1
	W2-2	1
	W3	130
	W3-1	7
	W5	8
	W6	8
	W8	50
	W9	50

# NOTE





Wear gloves and  
pay attention to  
sharp edges!

Pay attention to  
and watch the  
direction of the  
arrows on the  
sheets during  
assembly!





Position the  
channels over the  
top and bottom  
edges of the panels.

1. Front wall assembly: Assemble wall sheet F4 to the channel F2 first. Then assemble with channel F1 and channel F3, and install F5, F6 and F7 last of all.





SKETCH	PART NO.	QTY
	F1	1
	F2	1
	F3	1
	F4	1
	F5	1
	F6	1
	F7	1
	W3	12

2. Left wall assembly  
Connect wall sheet L3 with channel L1, L2, and tighten L1 and L2, L3 with screws W3.



SKETCH	PART NO.	QTY
	L1	1
	L2	1
	L3	1
	W3	4




3. Right wall assembly  
Connect wall sheet R3 with channel R1, R2, and tighten R1 and R2, R3 with screws W3.



QTY:1

SKETCH	PART NO.	QTY
	R1	1
	R2	1
	R3	1
	W3	4



4. Back wall assembly  
Assemble B1 and B2 first, then connect with B3 and B4.



QTY:1

SKETCH	PART NO.	QTY
	B1	1
	B2	1
	B3	1
	B4	1
	W3	11



5. Roof assembly: Note: Add W9 to the screws to seal against water. Assemble T1 and T2 first, then assemble T4 and T3,T5. Note that T3 and T5 are on top of T4.



QTY:1

SKETCH	PART NO.	QTY
	T1	1
	T2	1
	T3	1
	T4	2
	T5	1
	W3	17
	W9	17


6. When connecting front, back, left and right frame, front frame is outside the left and right frames, but back frame is inside them.





QTY:1


SKETCH	PART NO.	QTY
	FRONT	1
	LEFT	1
	RIGHT	1
	BACK	1
	W3	22




7.Fix F10 with screws



SKETCH	PART NO.	QTY
	F10	1
	W3	2




8. Put the roof on the top, fasten it at pre-punched locations with screws.  
Note: add W9 to the screws to seal against water.











SKETCH	PART NO.	QTY
	TOP	1
	W3	18
	W9	18



9. Left door assembly





Install DL3 and DL5, and then install DL1 and DL4 to DL2. Pay attention that the DL6 parts are inserted into DL3 and DL5. The middle screws of DL6 should be drill from the reverse side.



SKETCH	PART NO.	QTY
	DL1	1
	DL2	1
	DL3	1
	DL4	1
	DL5	1
	DL6	2
	W1	2
	W3	26



10. Fix the door to the shed, then install W2-1; ensure that the left of W2-1 is inserted into gap of DL3. Install W2-2 to W2-1; use W3 to fix W2-2's buckle to Channel F7.



SKETCH	PART NO.	QTY
	W3-1	7
	W3	4
	W2-1	1
	W2-2	1

11.Set the anchors.

SKETCH	PART NO.	QTY
	W5	8
	W6	8



**Note:** Please push 'screw cover' W8 onto the ends of screws inside the shed for to protect against the sharp ends.